



DIAPHRAGM AND PISTON PUMP PARTS

Item	Part No.	Description	Item	Part No.	Description
2	027367	Gasket (Bung Adapter)	31	003927	Piston Cylinder (piston pumps only)
3	048252	Bearing	32	003506	Piston Cover
4	048249	Packing		023060	Piston Cover, 1520T
	040046	Packing, 1520T	33	048247	Valve Plate
5	048254	Bearing Plate	34	048273	Diaphragm Assembly
6	048285	Valve Spring	35	048911	Pump Body
7	048260	Suction Screen	36	048245	Cover
	051616	Suction Screen, 1520T	37	026031	Inlet Fitting, 1" FNPT used w/bung adapter
8	048253	Fire Screen		048280	Inlet Fitting, 1" FNPT x 2" MNPT with vent hole
	051613	Fire Screen, 1520T		048491	Inlet Fitting, 1" FNPT x 2" MNPT without vent hole
9	048266	Vacuum Breaker (<i>Production prior to 2/27/98</i>)	38	026032	Fitting, 1" vertical outlet
	066570	Vacuum Breaker (<i>Production 2/27/98 or later</i>)		026056	Fitting, 1" vertical outlet, 1520T
	066527	Vacuum Breaker, 1520T		048267	Fitting, 3/4" side outlet <i>NOTE: Outlet fittings also require items 9 and 14 to prevent leakage.</i>
10	034916	Connecting Link	39	048296	1/4-20 x 7/8 Lg Hex Hd Thread Forming Screw
12	043020	Pin 1-15/32" long	40	048296	1/4-20 x 7/8 Lg Hex Hd Thread Forming Screw
13	020641	Clasp	41	051981	3/8-24 x 3/4 Lg Self-locking screw
14	048264	Retainer (except 1520T)		051977	3/8-24 x 7/8 Lg Self-locking screw, 1520T
15	048271	Diaphragm Retainer	42	053245	1/4-20 x 3/4 Lg Sq Hd Cup Pt set screw
16	048272	Diaphragm	43	068044	3/8 Lockwasher
17	048270	Shaft		068936	3/8 Lockwasher
	055895	Shaft (piston pumps only)	44	042355	3/32 x 3/4 Lg Cotter Pin
18	045662	Piston Retainer	45	047290	Pipe Plug, 3/4"
	045660	Piston Retainer, 1520T	46	043261	3/16 Dia x 1/2 Lg Roll Pin
19	045663	Piston Retainer	47	048286	Spring Retainer
	045661	Piston Retainer, 1520T	48	068155	1/4 Lockwasher
20	045705	Piston Cup (piston pumps only)	49	048244	Diaphragm Washer
21	048297	Push-On Ring	50	048246	Diaphragm Ring
	049531	Push-On Ring, 1520T	51	017278	Bushing - Hexagon, 1520T
22	048287	Push-On Ring	53	048296	1/4-20 x 7/8 Lg Hex Hd Thread Forming Screw
	049532	Push-On Ring, 1520T	54	039163	Locking Ring
23	048288	Valve			
	066941	Valve, 1520T			
24	048289	Valve Gasket			
	054150	Small Valve Seal, 1520T			
	054151	Large Valve Seal, 1520T			
25	029398	Handle and Grip Assy.			
26	045701	Piston Assembly			
	045702	Piston Assembly, 1520T			
27	048278	Valve Assembly			
	066942	Valve Assembly, 1520T			
28	026116	Bung Adapter Assembly			
29	027368	Ring - Square Cut			
	054092	Seal Ring Assembly, 1520T			
30	048243	Ring - Square Cut			
	054086	Cover Seal, 1520T			